

Origami - Cover stand for Galaxy Tab 3 10.1

Work, play and protect

Article number	EW1677
EAN code	8056045870278
Master carton	0
Casepack	0

OVERVIEW

- The origami design of the cover lets you position your tablet easily in every direction
- Protect your tablet from bumps and scratches
- Free access to the main controls
- Support for vertical and horizontal orientation
- Stable back support



Work, play and protect

This Ewent case lets you watch movies and send e-mail easily with just a simple touch.

Multiple viewing angles

Thanks to the "origami" shaped cover you can position your tablet in vertical and horizontal direction for comfortable typing. Use the horizontal position to watch movies and videos with a wider angle.

BOX CONTENTS

- Origami case